

Designing a FIR Filter Lab

Introduction

In this lab, you are shown one way of specifying, simulating, and implementing a FIR filter using the System Generator's FIR and FDATool blocks. The FDATool block is used to define the filter order and coefficients, and the FIR block is used for the Simulink simulation and design implementation in FPGA using Xilinx ISE. You are also able to verify the functionality of the design by running it through the actual hardware.

Note: There are completed examples in `.\labsolution\lab6` directory.

Objectives

After completing this lab, you will be able to:

- Enter your filter characteristics and generate coefficients using the FDATool block
- Simulate a design using the FIR block with the coefficients generated by the FDATool block
- Perform hardware-in-the-loop verification

Design Description

You are DSP Designer in a company. Your company is investigating using Digital Filters instead of analog for its Security Tag detectors in an attempt to improve performance and reduce cost of the overall system. This will enable the company to further penetrate the growing security market space. The specification of the single channel, single rate filter is specified below:

- Sampling Frequency (F_s) = 1.5 MHz
- $F_{stop\ 1}$ = 270 KHz
- $F_{pass\ 1}$ = 300 KHz
- $F_{pass\ 2}$ = 450 KHz
- $F_{stop\ 2}$ = 480 KHz
- Attenuation on both sides of the passband = 54 dB
- Pass band ripple = 1

The company has chosen to go with FPGAs due to their flexibility and time to market and performance advantages over DSP Processors. Your HDL design experience is limited and hence System Generator for DSP appears to be an excellent solution for implementing the filter in an FPGA, as you are already familiar with The MathWorks products.

Your manager has requested that you create a prototype of the filter to be implemented on their Atlys board prototype board that is almost complete. The prototype must be finished as quickly as possible for the imminent Aggressive Security convention, which is the industry's largest convention of the year, so it must not be missed.

Your manager has provided a starting model that includes input sources and output sink. Your design must be simulated using a Random Source and the chirp from the DSP Blockset. To analyze the output of the filter, input and output signals are displayed in a spectrum scope. A spectrum scope is used to compare the frequency response of the fixed-point FIR filter, which will be implemented in the FPGA.

Two different sources are used to simulate the filter:

- The chirp block, which sweeps between the specified frequencies of 0 to 750kHz
- The random source generator, which outputs a random signal of uniform distribution with a range of 0 to 1. Uniform is a better choice to drive a fixed-point filter because it is bounded.


Procedure

This lab is separated into steps that consist of general overview statements that provide information on the detailed instructions that follow. Follow these detailed instructions to progress through the lab.

This lab comprises 3 primary steps: You will generate coefficients for a FIR filter, model and simulate the FIR filter and, finally, perform hardware-in-the-loop verification.

Note: If you are unable to complete the lab at this time, you can download the original lab files for this module from the Xilinx University Program site at <http://www.xilinx.com/university>

General Flow for this Lab



Generate Coefficients for the FIR Filter

Step 1

1-1. Open bandpass filter model from lab6 in Matlab. Add the FDATool block from the Xilinx Blockset → DSP blockset to a design containing a DA FIR filter. Generate coefficients for the FIR filter in the using the FDATool block for the following specifications.

- Sampling Frequency (F_s) = 1.5 MHz
- Fstop 1 = 270 kHz
- Fpass 1 = 300 kHz
- Fpass 2 = 450 kHz
- Fstop 2 = 480 kHz
- Attenuation on both sides of the passband = 54 dB
- Pass band ripple = 1

1-1-1. Open the MATLAB command window by double-clicking on the MATLAB icon on your desktop, or go to **Start Menu → All Programs → MATLAB → R2010a → MATLAB R2010a**

1-1-2. In Matlab, change directory to **c:/xup/dsp_flow/labs/lab6/**

1-1-3. Open the **bandpass_filter.mdl** model from the MATLAB console window

1-1-4. Add the **FDATool** block by from **Xilinx Blockset → DSP** to the design

1-1-5. Enter the following filter parameters in the **FDATool Design Filter** window (**Figure 1**)

- Response Type: Bandpass
- Units: KHz
- Sampling Frequency (F_s) = 1.5 MHz
- Fstop 1 = 270 kHz
- Hint: Fpass 1 = 300 kHz
- Fpass 2 = 450 kHz
- Fstop 2 = 480 kHz
- Attenuation on both sides of the passband = 54 dB(Astop1 and Astop2 parameters)
- Pass band ripple = 1(Apass)

The screenshot shows the FDATool Design Filter window with the following settings:

- Response Type:** Bandpass (selected)
- Filter Order:** Minimum order (selected)
- Frequency Specifications:** Units: kHz, F_s : 1500, Fstop1: 270, Fpass1: 300, Fpass2: 450, Fstop2: 480
- Magnitude Specifications:** Units: dB, Astop1: 54, Apass: 1, Astop2: 54
- Design Method:** FIR Equiripple (selected)
- Options:** Density Factor: 16

Figure 1. Design a Filter in FDATool.

1-1-6. Click the **Design Filter** button to determine the filter order

The spectrum window will be updated and will look like as shown in Figure 2




Figure 2. Designed Filter's Magnitude Response.

Question 1

Based on the defined specifications, what is the minimum filter order?

1-1-7. Export the coefficients in the Workspace with Numerator variable name as **Num (Figure 3)** using **File → Export**

Note: This will add Num variable in your MATLAB workspace. For a FIR filter, Num represents coefficients that are used in the filter. This is also an optional step as the coefficients are still available through the FDATool block




Figure 3. Exporting Coefficients in the Workspace.

1-1-8. Type **Num** in the MATLAB console window to see the list of coefficients

1-1-9. Type **max(Num)** and **min(Num)** in the MATLAB console window to determine the maximum coefficient value that adequately specifies the coefficient width and binary point

Question 2

Fill in following information related to the coefficients

Maximum value: _____

Minimum value: _____

Model and Simulate the FIR Filter

Step 2

2-1. Add the FIR filter block from the Xilinx DSP library and associate the generated coefficients. Simulate the design and verify functionality. Add the convert block on the output of the FIR block to reduce the dynamic range. Simulate the design to verify functionality.

2-1-1. Add the **FIR (FIR Compiler 5.0)** filter block from the **Xilinx Blockset → DSP** library to the design and **constant** block from **Xilinx Blockset → Basic Blocks**

2-1-2. Double-click the **FIR** block and enter the following parameters in the block parameter window (**Figure 4**). Click OK.

- **Filter Specification**
 - **Coefficients** : xlfda_numerator('FDATool')
 - **Number of Coefficient Sets**: 1
 - **Filter type**: Single_rate
 - **Select format**: Sample_Period
- **Implementation**
 - **Filter Architecture**: Distributed Arithmetic
 - **Coefficient Structure**: Inferred
 - **Coefficient Type**: Signed
 - **Quantization**: Quantize_only
 - **Coefficients Width**: 12
 - **Coefficients Fractional Bits**: 12




Figure 4. FIR Filter Block Parameters.

- 2-1-3. Add and parameterize the **constant** block to **Boolean** and connect the blocks to have the design resemble to **Figure 5**




Figure 5. FIR Filter Block Based Design Ready for Simulation.

- 2-1-4. Double-click the **Gateway In** block and set the format to **FIX_8_6** and sampling period to **1/150000**
- 2-1-5. Select the **Chirp** Source and start the simulation
- 2-1-6. Bring the scope to the front and verify that the signal coming out of the FIR filter has been attenuated and they look like **Figure 6** and **Figure 7**, below.




Figure 6. Attenuation in Passband (Spectrum Scope).




Figure 7. Attenuation in Stopband (Spectrum Scope).

2-1-7. Select the **Random Source** and run the simulation (**Figure 8**)




Figure 8. Random Source (Spectrum Scope).

2-1-8. Stop the simulation

2-1-9. Add a **Convert** block (**Xilinx Basic Elements**) on the **FIR** output and configure it as **FIX_8_6** with **quantization** as **Truncate** and **Overflow** as **Wrap**

Note: Your design should look like that shown in **Figure 9**.




Figure 9. Completed FIR Filter Design.

2-1-10. Run the simulation using the Chirp signal and white noise inputs, noting the reduction in dynamic range due to the reduced number of output bits. See **Figure 10** and **11**.




Figure 10. Filter response due to chirp input.




Figure 11. Filter response due to white noise input.

Perform Hardware-in-the-Loop Verification

Step 3

3-1. Using the System Generator token, generate the hardware and verify that the design works through the hardware board. Simulate the design through Simulink.

3-1-1. Save the model as `bandpass_filter_hw.mdl`

3-1-2. Double-click the System Generator token and set the following parameters

In Compilation Window

- Compilation: **Hardware Co-Simulation → Atlys → JTAG**
- Synthesis Tool: **XST**
- Target Directory: **c:/xup/dsp_flow/labs/lab6/hwcosim (or ./hwcosim)**
- Create Testbench: **Unchecked**
- Create Interface document : **Unchecked**

In Clocking window

- Simulink system period: **1/1500000**

Leave rest of the settings to default and Click **Apply**

Note: Make sure the System Generator block's window shows Spartan6 xc6slx45-2csg324 as the device.

If the **Atlys** is not existed, you have to **readme_atlysboard.docx** and install the plugin

3-1-3. Click the **Generate** button

3-1-4. A dialog box opens showing the compilation process progress as shown in **Figure 12**




Figure 12. Compilation Progressing In Command Window.

3-1-5. When the generation is successfully completed, a new Simulink library window will open up and a compiled block with appropriate number of inputs and outputs will be displayed




Figure 13. Compiled Block Opened in a New Simulink Window.

3-1-6. Copy the compiled block into the design and connect it as shown in **Figure 14**





Figure 14. Complete Design Ready for the Hardware in the Loop Simulation.

3-2. Connect the hardware board and simulate the design through Simulink.

3-2-1. Connect the power cable to the hardware board

3-2-2. Connect the download cable between the board and PC

3-2-3. Double-click on the hardware co-simulation block and select the **Digilent USB JTAG Cable** from the cable tab, which is used for configuring the FPGA on the Atlys board

3-2-4. Select random source and click the **run** button () in the Simulink window to run the simulation. The configuration bit file will be downloaded and a simulation will be run

3-2-5. The simulation result in the output scope will display output of the Simulink simulator on the top and the hardware output in the bottom plots (**Figure 15**)




Figure 15. Simulation Result Showing Simulator's Output on the Top and Hardware Output at the Bottom.

3-2-6. Click stop button and turn off the power

3-2-7. Save the model

3-3. Using the System Generator token, generate the library component for the hardware in the loop using point-to-point Ethernet protocol. Wire the generated block and verify the functionality using point-to-point Ethernet protocol.

3-3-1. Remove the hardware in the loop component and associated connections from the design and save the design as **mac_bandpass_ethernet_hw.mdl**

3-3-2. Double-click the System Generator token and set the following parameters

In Compilation window

- Compilation: **Hardware Co-Simulation → Atlys → Ethernet → Point-to-Point**
- Synthesis Tool: **XST**
- Create Testbench: **Unchecked**
- Target Directory: **c:/xup/dsp_flow/labs/lab6/hwcosim_eth (or ./hwcosim_eth)**
- Create Interface Document: **Unchecked**

In Clocking window

- Simulink sytem period: **1/1500000**

Leave rest of the settings to default and click **Apply**

Note: Make sure the System Generator block's window shows Spartan6 xc6slx45-2csg324 as the part.

If **Atlys** is not shown, then refer **readme_atlysboard.docx** and install the plugin

3-3-3. Click the **Generate** button

3-3-4. When the generation is successfully completed, a new Simulink library window will open up and a compiled block with appropriate number of inputs and outputs will be displayed

3-3-5. Copy the compiled block and connect it in the design

3-3-6. Double-click on the **hardware co-simulation block** and perform following configurations and then click **OK**




Figure 21. Configure the Compiled Block for Ethernet-based Co-Simulation.

- 3-3-7. Run the simulation. Observe that the FPGA is programmed using JTAG cable but the actual simulation is carried out using Ethernet. Depending on the communication speed you will experience the speedup
- 3-3-8. Stop the simulation
- 3-3-9. Save the model and exit Matlab

Conclusion

In this lab, you learned how to use FDATool to create filter coefficients and use them from the FIR filter block. You used the Resource Estimator block to estimate the resources.

Answer

1. Based on the defined specifications, what is the minimum filter order?

_____ 91 _____

2. Fill in following information related to the coefficients

Maximum value: _____ 0.1610 _____

Minimum value: _____ -0.1541 _____